

# 30000/120



STEP 01



- IT** • Rimuovere il vecchio teflon con una lama
- EN** • Remove the old teflon with a cutter / blade
- ES** • Remover el viejo teflon con una ttoja

STEP 02



- IT** • Accertarsi che la sede sia pulita
- EN** • Make sure that the place is clean
- ES** • Asegurarse que la sede sea limpia

STEP 03



- IT** • Posizionare manualmente il nuovo teflon sul cono
- EN** • Manually place the new teflon on the cone
- ES** • Colocar manualmente el nuevo teflon sobre el cono

STEP 04



- IT** • Portare il teflon alla base del cono
- EN** • Slide the teflon to the base of the cone
- ES** • Llevar el teflon a la base del cono

STEP 05



- IT** • Appoggiare il cono sull'estremità dell'iniettore
- EN** • Lean the cone on the top of the injector
- ES** • Apoyar el cono en extremidad del inyector

STEP 06



**IT** • Inserire il teflon dal cono alla sede dell'iniettore

**EN** • Slide the teflon from the cone to its place on the injector

**ES** • Insertar el teflon desde el cono a la sede del inyector

STEP 07



**IT** • Prendere l'inseritore dal lato "A" e posizionarlo sull'iniettore

**EN** • Take the inserter from side "A" and place it on the injector

**ES** • Coger el insertador desde el lado "A" y colocarlo sobre el inyector

STEP 08



**IT** • Spingere l'inseritore fino a fine corsa

**EN** • Push the inserter all the way down

**ES** • Empujar el inseridor hasta el final

STEP 09



**IT** • Ruotare l'inseritore da lato "B" e posizionarlo sull'iniettore

**EN** • Turn the inserter on side "B" and place it on the injector

**ES** • Rotar el insertador desde el lado "B" y colocarlo sobre el inyector

STEP 10



**IT** • Spingere l'inseritore fino a fine corsa

**EN** • Push the inserter all the way down

**ES** • Empujar el insertador hasta el final

STEP 11



**IT** • ATTENZIONE: controllare che il teflon sia correttamente inserita

**EN** • ATTENTION: double check that the teflon is inserted properly

**ES** • ATENCION: controlar que el teflon este insertado adecuadamente